


Making Connections



It is the responsibility of the service technician to prepare cables of proper size and length when using the Phoenix connector(s) provided.


- ▶ **CAUTION:** Assure the wire colors correctly correspond to the specific ports on both the CB-50 and CA-1000.

1



Insert red lead wire (from CA-1000) into the VE1 port of the 4-pin Phoenix terminal and tighten terminal screw as shown above. Next, take the white wire and tighten it in the VE2 Phoenix port. Lastly, insert and tighten the black wire in the VE- port. Recommended cable is Carol E2103S (or equivalent) plenum rated 22 AWG, (cable not included). See "What's in the Box" for parts listing.

2



Once the connections to the CB-50 and CA-1000 are made (amplifier needs to also be hooked up), turn the control dial to test volume and sound.

What's in the Box



The list of components in the box contains the following items from top left to right: (1) CB-50 volume knob assembly and wall cover plate, and (2) 4-Pin Phoenix connector.

09.03.09